




60019

CITY










1x

1




2x

2





3




4




1x

4




2x

5




2x





1x

6






1x




1x

7



2x

8






1x



1x


9





2x

10






1x



1x


11





2x


12





2x


13





1x

14






1x



1x

15






2x

2x

16






1x



1x

17





1x




1x



2x

18





2x




1x

19




2x





2x

20






2x



2x


21






1x

22




23





2x

24






2x

25



2x






1x




1x

26



27






1x



1x

28






1x



1x

29






1x



1x


30





1x

1



1x


2





2x

3




2x

4






5






6



7







2x




2x

8



31





1x



1x



1x


1



2



32





1x


1



2




33





1x

34




38



1x

35






1x


36

1




2





37



LEGO

CITY





CITY



60008



60007



60006



Nintendo®



CITY
UNDERCOVER



LEGO® City: Undercover software ©2013 TT Games Publishing Ltd. ©2013 The LEGO Group. All rights reserved.

Wii U™



1x
4547489



3x
4658973



1x
485501



1x
6031947



2x
302301



1x
302201



2x
4598527



1x
306801



1x
4287708



1x
4287707



1x
243201



4x
6011380



1x
623901



1x
301021



1x
306221



1x
4526929



1x
4527765



2x
4121934



2x
6045937



2x
4116617



2x
4160406



1x
4180504



1x
4180533



2x
4171662



1x
459921



1x
4298617



1x
6032178



2x
4540382



1x
9341



2x
4515354



1x
4550348



1x
302324



2x
242024



1x
4549896



3x
241224



1x
4613344



1x
4600177



1x
4261572



1x
6022320



1x
9553



2x
407026



2x
4504382



1x
4188534



2x
4613153



2x
302426



1x
4565323



1x
4243819



3x
244526



1x
4283047



1x
4209003



1x
4283046



1x
4209013



1x
6021504



1x
408326



1x
9339



1x
6036006



1x
396226



1x
452226



1x
400626



4x
4508215



1x
4244573



1x
4288003



2x
4617848



1x
244126



1x
4142731



1x
4244363



2x
4201019



4x
3000844



2x
3005749



1x
4163306



1x
4621774



1x
4567338



1x
6037431



1x
4211388



2x
4211387



1x
4211529



2x
4211451



2x
4494475



1x
4211397



1x
4211395



1x
6030711



4x
4594238



2x
6045988



2x
4640844



1x
4211373



1x
4226995



2x
4211758



2x
4211807



2x
4210660



1x
4211055



4x
4210633



1x
6005463



1x
4502068



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346



CITY



60022



60021



60020



60019